


New Serial number construction

9th. July 2009

(1) 16 column serial number


- 1 Printer (Now 12 columns)
- 2 Reader/Writer (Now 10 columns)
- 3 Mechanism (Now 12 or 10 columns)
- 4 Control Board (Now 13, 12 or 8 columns)
- 5 Power Supply Board (Now 13, 12 or 8 columns)
- 6 I/F Board (Now 13, 12 or 8 columns)
- 7 Driver PCB (R/W only) (Now 8 columns)

* Concerning 'Purchased unit', for example, Power supply board for TSP100 or IFBD-HE05/06 don't follow this rule.



(2) 6 column serial number

- 1 Small PCB like operation panel board of HSP7000 (Now 6 or 5 columns)



(3) 8 column serial number

- 1 Print head (Now 8 or 6 columns)

